

TerraCast®

PRODUCTS

BURIAL BASE MAILBOX POST INSTALLATION INSTRUCTIONS

1. To install the TerraCast® Mail Box Post, a hole must be dug as shown in the illustration. Hole dimensions: minimum 13'' dia. X 30'' deep
2. The post is then set into the hole. Two bags of premixed concrete and water are added. Please follow the written instructions on the premix concrete. The concrete can be mixed in the hole. Make sure the post is level. The remaining soil can be placed on top of the concrete. Let the concrete cure for three hours.
3. Place the mail box with metal plate attached on top of the post and insert the PVC piece into the recessed area. Push down firmly. Using a cordless drill, insert one self-driving screw into the post approximately ½'' from the top to secure the mail box to the post. Insert one screw on each side.

